

BMW iX1 U11 2023->

Installation instructions *frunk*

1. Pull off the motor cover with a jerk. pic 1



pic 1

2. Install *frunk*:

- Position the vibration dampers (A, B, C and D) mounted on the *frunk* on the existing spacer bolts. pic 2
- By pressing on the attachment point (A, B, C and D,) in alphabetical order, the *frunk* is fixed on the spacer bolts. pic 3
- Make sure that all four vibration dampers snap into place on their respective spacer bolts.



pic 2

3. Check:
Check for a tight fit - done!



pic 3

Notes:

- Do not load above the top edge of the *frunk*.
- Maximum load 10kg.

Montering av Frunk

1. Dra bestemt oppover for å fjerne motordekselet. pic 1

2. Sett frunken inn i motorrommet.
• Plasser frunken over de originale kulehodene A, B, C og D.

pic 2

• Press bestemt ned på festepunktene.

pic 3

• Sjekk at alle 4 punker sitter som de skall på plasseringen.

3. Se over alle punkter.
Ferdig!

Obs:

- Last ikke over toppen av frunken
- Max last: