

# Installation instructions *frunk*

VW ID.4/ID.5 2020->

1. Align the retaining clips:  
The retaining clips (A, B, C and D) mounted on the *frunk*, according to the position of the pipe support.

pic 1



pic 1

2. Install *frunk*:  
By pressing on the retaining clips (A, B, C and D,) in alphabetical order, the *frunk* is fixed on the pipe support.

pic 2



pic 1

3. Check:  
Check for a tight fit - done!

pic 3



pic 3

## Notes:

- Do not load above the top edge of the *frunk*.
- Maximum load 10kg.

## Montering av Frunk

1. Juster klippsene på frunken med feste plassene A, B og C.

pic 1

2. Sett inn frunken og press denne ned på stål rammen på punkt A, B, C og D.

pic 2

3. Sjekk over monteringen.

pic 3

## Obs:

- Last ikke over toppen av frunken
- Max last: 10kg