

VW ID.7 2024->

Installation instructions *frunk*

1. Align the retaining clips:
The retaining clips (A, B, C and D) mounted on the *frunk*, according to the position of the pipe support.

pic 1



pic 1

2. Install *frunk*:
By pressing on the retaining clips (A, B and C) in alphabetical order, the *frunk* is fixed on the pipe support.

pic 2



pic 2

3. Check:
Check for a tight fit - done!

pic 3



pic 3

Notes:

- Do not load above the top edge of the *frunk*.
- Maximum load 10kg.

Montering av Frunk

1. Juster klippene på frunken med feste plassene A, B og C.

pic 1

2. Sett inn frunken og press denne ned på stål rammen.

pic 2

3. Sjekk over monteringen.

pic 3

Obs:

- Last ikke over toppen av frunken
- Max last: 10kg